HALO 2

Wireless pH Tester for Bread & Dough

with built-in specialized electrode



INSTRUCTION MANUAL



Dear Customer,

Thank you for choosing a Hanna Instruments product.

Please read this instruction manual carefully before using this instrument.

This manual will provide you with the necessary information for correct use of this instrument, as well as a precise idea of its versatility.

If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com or view our contact list at www.hannainst.com.

TABLE OF CONTENTS

1. Preliminary Examination	4
2. Specifications	4
3. General Description & Intended Use	5
Operating Modes	5
Probe Features	5
4. Functional Description & LCD Display	5
5. General Operations	
Turning the Tester On & Off	6
Battery Replacement	6
6. Setup	
Temperature Unit	
Auto-Off Interval	
Calibration Points	
Buffer Set	
pH Resolution	
Bluetooth® Wireless Mode	
Bluetooth Pairing	
Date & Time	
7. Bluetooth	
8. Hanna Lab Application	
Tag a Measurement	
9. Calibration	
Preparation & Guidelines	
Procedure	
With Hanna Lab App (Up to Four-Point Calibration)	
10. Care & Maintenance	
Storage	
11. Warning & Error Messages	
12. Accessories	
13. Abbreviations	
Certification	
Recommendations for Users	
Warranty	10

1. PRELIMINARY EXAMINATION

Remove the tester and accessories from packaging and examine them carefully. For further assistance, please contact your local Hanna Instruments office or email us at tech@hannainst.com.

Each H19810382 is supplied with a starter kit consisting of:

- pH 4.01 buffer solution, 20 mL sachet (2 pcs.)
- pH 7.01 buffer solution, 20 mL sachet (2 pcs.)
- Electrode cleaning and disinfection solution for bread and dough deposits, 20 mL sachet (2 pcs.)
- Electrode storage solution, 13 mL dropper bottle (1 pc.)
- 3V Lithium battery CR2032
- · Instrument quality certificate and Instruction manual

Note: Save all packing material until you are sure that the tester works correctly. Any damaged or defective item must be returned in its original packing material with the supplied accessories.

2. SPECIFICATIONS

	рН	0.00 to 12.00 pH	
Range	mV *	pH/mV conversion	
	Temperature**	0.0 to 60.0 °C (32.0 to 140.0 °F)	
	pН	0.01 or 0.1 pH	
Resolution	mV *	0.1 or 1 mV	
	Temperature	0.1 °C; 0.1 °F	
A	pН	±0.05 pH	
Accuracy	Temperature	±0.5 °C; ±0.9 °F	
Calibration	Up to three points or four points * Automatic buffer recognition with Standard buffers Hanna (pH 1.68 *, 4.01, 7.01, 10.01) or NIST (pH 1.68 *, 4.01, 6.86, 9.18)		
Temperature compensation	Automatic (ATC) or Manual (MTC) *		
Electrode	Body material Glass Junction Reference cell Electrolyte Tip / Shape Outer diameter Length	Polyvinylidene Fluoride (PVDF) Low Temperature (LT) Open Double, Ag/AgCl Viscolene Conic, Ø 6 x 10 mm (Ø 0.23 x 0.39") 13 mm (0.51") 75 mm (2.95")	
Battery type	3V Lithium — CR2032		
Battery life	Approximately 1000 hours (500 hours with Bluetooth enabled)		
Environment	0 to 50 °C (32 to 122 °F)		
Casing	IP65 ingress protection		
Dimensions / Weight	51 x 146 x 21 mm (2.0 x 5.7 x 0.8") / 45 g (1.6 oz.)		

^{*} Available with Hanna Lab App

^{**} Measuring outside the recommended operating temperature range may damage the gel electrolyte and void product warranty.

Note: The tester can display measurements from -2.00 to 16.00 pH. Measurements outside of the pH range will flash. In this case assess the integrity of the tester and the type of measured sample.

3. GENERAL DESCRIPTION & INTENDED USE

HI9810382 is a professional wireless pH tester, part of Hanna Instruments HALO2 family.

- The integrated Bluetooth module allows the tester to be connected to a compatible smart device with the Hanna Lab App.
- The tester has a compact, waterproof casing, and automatic pH calibration at up to three points, or four points when
 used with the Hanna Lab App.
- Automatically compensated temperature readings are displayed on a large LCD.
- Accurate and easy to use, the tester is ideal to measure the pH during baking processes and it meets the food-hygiene
 and Hazard Analysis Critical Control Point (HACCP) regulations.

Operating Modes

The H19810382 can be used as a stand-alone pH tester or connected to the Hanna Lab App.

The Hanna Lab App turns a compatible smart device into a full-featured pH meter. Features include: electrode condition, GLP with time-stamp, live-readings, mV resolution, manual temperature compensation, stability criteria, calibration reminder, pH (mV) and temperature alarms, tester ID, and data sharing.

Probe Features

The food grade **PVDF body material** is easy to clean and disinfect. Resistant to most chemicals (e.g. solvents, sodium hypochlorite), ultraviolet light, and fungal growth, the PVDF body also has high-abrasion resistance and mechanical strength.


The conical tip allows for easy penetration into solids and semisolids.

The **double junction** design presents a silver-free electrolyte solution interacting with the sample, making the electrode less susceptible to clogging and guaranteeing a fast response and stable reading.

Built-in temperature sensor at the tip of the pH electrode allows rapid determination of the sample temperature and a high-accuracy temperature reading.


4. FUNCTIONAL DESCRIPTION & LCD DISPLAY

Front & Back view





LCD display



- Calibration indicator
- 2 Stability indicator
- 3 Battery percentage indicator
 - Battery icon
- 5 Bluetooth icon
- Temperature compensation
- 7 Second LCD line
- 8 Temperature unit
- 9 First LCD line
- 10 Measurement unit

5. GENERAL OPERATIONS

Turning the Tester On & Off

- Place the tester face down on a clean, dry surface. Rotate the battery cover on the back of the tester counterclockwise
 and set it aside. Remove the battery insulation film.
- Press the ON/OFF button to turn the tester on or off. Initialization screen displays all LCD segments, followed by the
 battery percentage. The tester enters measurement mode. Before the tester turns off, "BFF FWR" is displayed briefly.
- Press and hold the ON/OFF button to turn the tester off when connected to Bluetooth.

Battery Replacement

- 1. Turn off the tester. Turn the tester face down and rotate the battery cover counterclockwise.
- 2. Set the battery cover aside. Press the metallic pin to push old battery out.
- 3. Place the new battery with positive (+) sign facing out.
- 4. Reset the date and time in setup, or connect to the Hanna Lab App to update it automatically.
- Align the mark on the cover with the open lock icon () on the case. Rotate the cover clockwise until the mark on the cover aligns with the closed lock icon ().

Note: Only use specified battery type. Dispose of old battery in accordance with local regulations.



6. SETUP

The Setup button is located inside the battery compartment. After Setup configuration, replace the cover.

Setup Menu Navigation

- Press the Setup button to enter Setup mode and navigate menu items.
- To exit Setup mode, press the Setup button after "SEL TIME" option is displayed.
- Press the ON/OFF button to configure menu item options.

Temperature Unit

Option: °C or °F Press ON/OFF button to select desired

temperature unit.

Auto-Off Interval

Option: 8, 60 min., or "----" (disabled)
Press ON/OFF button to select desired interval.
To save battery life, after the selected auto-off

To save battery life, after the selected auto-off interval has elapsed, the tester will automatically turn off.



OF

Calibration Points

Option: 2P or 3P

Press ON/OFF button to select between up to two- or up to three-point calibration.

Buffer Set

Option: 7.01 pH (Hanna) or 6.86 pH (NIST) Press ON/OFF button to select the calibration buffer set (Hanna or NIST).

pH Resolution

Option: 0.01 pH or 0.1 pH

Press the ON/OFF button to select resolution.

Bluetooth Wireless Mode

Option: On, PAIr, or OFF

Press ON/OFF button to select Bluetooth

option at start-up.



Bluetooth Pairing

Option: dEL PAIr

Press ON/OFF button to delete saved paired device

Date & Time

Option: SEt TIME

Press ON/OFF button to set the date and time

Ontion: YEAR MO DAY HOUR and MIN



Use the Setup button to select the option and press the ON/OFF button to change the selected option.

7. BLUETOOTH

With "PRI c RELL" or "On RELL" selected in Setup, the Bluetooth icon (*) will blink for up to 45 seconds, indicating the tester is in discoverable mode. Once connected the icon will stop blinking. If not connected the icon is not displayed

- Select "On Relat", to enable Bluetooth without bonding.
- Select "PRI r 30.11", to enable Bluetooth with bonding. A 6-digit bonding pin is displayed the first time the tester and smart device are paired. Once the devices are paired, the bonding pin is not required when reconnected.
- Select "OFF THELL", to disable Bluetooth.
- Select "dEL PAIR", to delete all paired devices. If PAIr BLU is enabled, a bonding pin will need to be re-entered.

8. HANNA LAB APPLICATION

- The Hanna Lab App is available on the App Store® and on Google Play.
- Consult the Help section of the application for information on calibration, measurement, data logging, and sharing.
- When the tester is in discoverable mode, it will appear in the list of "Available Devices".
- Within the application, tap "Connect" to pair the tester with the device. All readings are transmitted directly to the application.

Tag a Measurement

Once connected to the application, the ON/OFF button can be pressed to tag the current reading.

- Press the ON/OFF button from measurement mode. The display shows "SEE TRIS", followed by "- TRIS".
- The reading on the application will flash green and the note icon (\bigcirc) will be displayed. Tap the note icon (\bigcirc) to add an annotation





9 CALIBRATION

Preparation & Guidelines

- 1. Remove the probe from the plastic storage cap. Save the cap for probe storage.
- 2. Rinse off any storage solution or salts that may be on the body.
- 3. Verify there is solution inside the pH bulb by shaking the probe down to restore continuity as the solution may have moved up the stem during shipping.
- 4. For best results, use a rinse beaker and a separate calibration beaker for each buffer. Discard rinsing buffers after use.

Procedure

For most applications it is recommended to start with pH 7.01 buffer (or pH 6.86).

To restore factory defaults, press and hold the ON/OFF button. "[RL [] R" is displayed.

Note: It is recommended to calibrate the electrode with buffers at the temperature it will be used at.

Stand-Alone Tester (Up to Three-Point Calibration)

- 1. Rinse the electrode tip with purified water and blot dry. Then rinse with the buffer being used for calibration.
- 2. Press and hold ON/OFF button until "EAL MEDIE" is displayed.
- 3. When "70 ! USE" or "6.86 USE" is displayed with "CAL" tag blinking, place the tip of the electrode in the correct buffer





4. When the buffer has been recognized, "REE" is displayed.

"WFIIT" is displayed with the stability indicator (\$\hat{\mathbf{Z}}\) blinking until the reading is stable. Wait until the measurement is stored and the stability indicator disappears.





To save a one-point calibration and return to measurement mode, press the ON/OFF button.
 "ERL SAVE" is displayed briefly.

With 2P option selected

- Place the tip of the electrode in the second buffer rinse beaker, then in the second calibration buffer. Wait until the measurement is stored and the stability indicator disappears.
- After the second point has been stored, "EAL SAVE" is displayed briefly and the tester will return to measurement mode automatically.

With 3P option selected

- Place the tip of the electrode in the second buffer rinse beaker, then in the second calibration buffer. Wait until the measurement is stored and the stability indicator disappears.
- Place the tip of the electrode in the third buffer rinse beaker, then in the third calibration buffer. Wait until the measurement is stored and the stability indicator disappears.
- After the third point has been stored, "EAL SAVE" is displayed briefly and the tester will return to measurement mode automatically.

With Hanna Lab App (Up to Four-Point Calibration)

Connect the tester to the Hanna Lab App and follow the calibration procedure.

See the App Help section for the calibration procedure.

10. CARE & MAINTENANCE

- Never immerse the tester over the maximum immersion level.
- Fresh buffers should be used for each calibration. Once the sachets are opened the buffer value can change over time.
- If the electrode is slow or sluggish, soak it in cleaning solution for 20 minutes. Rinse with water and hydrate the
 electrode in storage solution for a minimum of 30 minutes before calibrating.
- If measurements are taken successively, rinse the probe thoroughly in distilled or deionized water to eliminate cross-contamination between measurements.

Storage

To ensure a guick response, the glass tip and junction should be kept hydrated.

When not in use, add a few drops of storage solution to the storage cap. If storage solution is not available, pH 4.01 or pH 7.01 buffer can be used.

Note: Do not store the electrode in distilled or deionized water.

11. WARNING & FRROR MESSAGES



"---- WRNG" displayed during calibration.
Invalid buffer.
Check the buffer value and use fresh buffer.



Measured value displayed blinking. Measured value is out of electrode range. Clean the electrode to improve condition.



Battery icon (a) displayed blinking.
Battery is below 10 %, replace the battery.



"BAtt DEAD" and tester turns off. Depleted battery, replace the battery.

12. ABBREVIATIONS

ATC Automatic Temperature Compensation

GLP Good Laboratory Practice

MTC Manual Temperature Compensation

NIST National Institute of Standards and Technology

13 ACCESSORIES

Ordering Information	Product Description	
pH Buffer Solution		
HI50016-02	pH 1.68 buffer solution, 20 mL sachet (25 pcs.)	
HI70004P	pH 4.01 buffer solution, 20 mL sachet (25 pcs.)	
HI70006P	pH 6.86 buffer solution, 20 mL sachet (25 pcs.)	
HI70007P	pH 7.01 buffer solution, 20 mL sachet (25 pcs.)	
HI70009P	pH 9.18 buffer solution, 20 mL sachet (25 pcs.)	
HI70010P	pH 10.01 buffer solution, 20 mL sachet (25 pcs.)	
HI77400P	pH 4.01 & 7.01 buffer solution, 20 mL sachet (10 pcs., 5 each)	
HI770710P	pH 10.01 & 7.01 buffer solution, 20 mL sachet (10 pcs., 5 each)	
Electrode Cleaning Solution		
HI700601P	Electrode cleaning solution for general use, 20 mL sachet (25 pcs.)	
HI700684P	Electrode cleaning and disinfection solution for bread and dough deposits, 20 mL sachet (25 pcs.)	
Electrode Storage Solution		
HI70300L	Storage solution, 500 mL	
HI70300M	OOM Electrode storage solution, 230 mL	
HI70300S	Electrode storage solution, 30 mL dropper	
HI9072	Electrode storage solution, 13 mL dropper	

RECOMMENDATIONS FOR LISERS

Before using this product, make sure it is entirely suitable for your specific application and for the environment in which it is used. Any variation introduced by the user to the supplied equipment may degrade the tester's performance. For your and the tester's safety do not use or store it in hazardous environments.

WARRANTY

H19810382 is warranted for a period of one year against defects in workmanship and materials when used for its intended purpose and maintained according to instructions. This warranty is limited to repair or replacement free of charge. Damage due to accidents, misuse, tampering, or lack of prescribed maintenance is not covered. If service is required, contact your local Hanna Instruments office. If under warranty, report the model number, date of purchase, serial number, and the nature of the problem. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the tester is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization (RGA) number from the Technical Service department and then send it with shipping costs prepaid. When shipping any product, make sure it is shipped back in compliance with shipping regulations, thoroughly cleaned and free of any chemicals, and is properly packaged for complete protection.

MAN9810382 10/21

CERTIFICATION

All Hanna Instruments conform to the CE European Directives.

Disposal of Electrical and Electronic Equipment. The product should not be treated as household waste. Instead, hand it over to the appropriate collection point for the recycling of electrical and electronic equipment, which will conserve natural resources.



RoHS



Disposal of waste batteries. This product contains batteries, do not dispose of them with other household waste. Hand them over to the appropriate collection point for recycling. Ensuring proper product and battery disposal prevents potential negative consequences for the environment and human health. For more information, contact your city, your local household waste disposal service, or the place of purchase.

Regulatory Notices for stand-alone, Bluetooth, low-energy modules

All modules have identical operation. All references to US FCC Rules and Canadian RSS standards on device classification and operation, listed here under BMD-300 Module, apply to all models noted here. Remove the battery cover to check the installed module.

BMD-300 Module

United States (FCC) FCC ID: 2AA9B04

This device complies with FCC Rules, Part 15, Subpart C "Intentional Radiators" and Subpart B, Chapter §15.105. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case, users are required to correct the interference at their own expense.

Canada (ISED) IC: 12208A-04

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not acuse interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Australia / New Zealand (RCM) RMD-300 complies with the AS/NZS 4268-2017

Japan (MIC) (R210-106799	South Korea (KCC) R-CRM-Rgd-BMD-300	
Brazil (ANATEL): Contains ANATEL approved module # 00820-21-05903.	Mexico (IFETEL): Este equipo contiene el módulo con IFT #: NYCE/CT/0146/17/TS.	

BMD-350 Module	Module	
United States (FCC) FCC ID: 2AA9B05	Canada (ISED) IC: 12208A-05	
Japan (MIC) (R210-108944	Australia / New Zealand (RCM) BMD-350 complies with the AS/NZS 4268:2017	
Eurasia (EAC) EAЭC N RU Д-US.HA27.B.00650/18	Brazil (ANATEL) Contains ANATEL approved module # 00857-21-05903	
China (SRRC) CMIIT ID: 2018DJ7255	Mexico (IFETEL) Este equipo contiene el módulo con IFT #: RCPRIBM18-1491	

ANNA-B112 Module			
United States (FCC) FCC ID: XPYANNAB1	Canada (ISED) IC: 8595A-ANNAB1		
Contains Transmitter Module Taiwan (NCC) 內含發射器模組: ((((CCAI18LP2200T2	South Korea (KCC) R-C-ULX-ANNA-B112		
South Africa (ICASA) ICASA TA-2019/1203 Approved	China (SRRC) CMIIT ID: 2021DJ6698		

Australia / New Zealand (ACMA) ANNA-B1 complies with AS/NZS 4268:2012 standard

Japan (MIC) 📦 🛮 🗗 🖺 204-810005

The module complies with the Japanese Technical Regulation Conformity Certification of Specified Radio Equipment (ordinance of MPT N°. 37, 1981), Article 2, Paragraph 1, Item 19 "2.4 GHz band wide band low power data communication system".

O3850-19-05903

Brazil (ANATEL) This equipment operates on a secondary basis and, consequently, must accept harmful interference, including from stations of the same kind, and may not cause harmful interference to systems operating on a primary basis.

World Headquarters

Hanna Instruments Inc. Highland Industrial Park 584 Park East Drive Woonsocket, RI 02895 USA www.hannainst.com



MAN9810382 Printed in ROMANIA