HI99171

Portable Waterproof Leather & Paper pH Meter



INSTRUCTION MANUAL



Dear Customer,

Thank you for choosing a Hanna Instruments product. Please read this instruction manual carefully before using this meter.

This manual will provide you with the necessary information for correct use of this meter, as well as a precise idea of its versatility.

If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com or view our worldwide contact list at www.hannainst.com.

All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner, Hanna Instruments Inc., Woonsocket, Rhode Island, 02895, USA.

4
5
6
7
8
8
14
15
16
17
18
19
19

PRELIMINARY EXAMINATION

Remove the instrument and accessories from the packaging and examine it carefully to make sure that no damage has occurred during shipping. Notify your nearest Hanna Instruments Customer Service Center if damage is observed.

Each H199171 is delivered in a rugged carrying case and is supplied with:

- H114143 pH/temperature probe with flat tip and DIN connector with 1m (3.3') cable
- HI70004 pH 4.01 buffer (1 sachet)
- HI70007 pH 7.01 buffer (1 sachet)
- H1700680 electrode cleaning solution for cellulose deposits (2 sachets)
- HI70960 preparation solution for solid or semi-solid samples (30 mL)
- 100 mL beaker (1 pcs.)
- 1.5V AAA alkaline batteries
- Instrument quality certificate
- Electrode quality certificate
- Instruction manual

Note: Save all packing material until you are sure that the instrument works correctly. Any damaged or defective item must be returned in its original packing material with the supplied accessories.

GENERAL DESCRIPTION AND INTENDED USE

H199171 is a lightweight, portable pH meter supplied with a specially designed pH electrode intended for the direct determination of pH on flat surfaces, such as leather or paper. During production of cartons and paper used for food packaging, pH measurements provide a useful gauge of product compatibility.

The pH of a piece of paper is usually considered one of the most reliable indices of its permanence. Historians require a convenient nondestructive method to determine the pH of valuable or irreplaceable documents.

Leather technicians measure the pH of the product during production to preserve the fiber structure and prevent damage. These readings are used to optimize the dyes, coatings and softening agents.

The HI99171 portable pH meter together with a HI14143 combination pH electrode (when immersed in a drop of water on the surface of the sample), can determine the pH of the surface with high accuracy and repeatability without the requirement of sample destruction.


The HI99171 features a two button operation system and is simple to use. The HI99171 has a waterproof and compact casing, large dual-line display, and automatic pH calibration at one or two points.

The HI14143 offers numerous features that improve pH testing for surface measurements. The flat tip of the HI1413 provides optimal contact between the sample and the sensor. The HI14143 features low resistance pH glass that responds quickly to the sample. It also has an open junction design and utilizes a non-flowing gelled reference electrolyte so there is no flow rate variability affecting the measurement. Both the pH sensing surface and reference junction come into direct contact with the surface and equilibrate quickly and reproducibly.

H114143 pH electrode has a built-in temperature sensor for temperature compensated pH readings and contains an integrated pH sensor preamplifier to provide stable measurements in electrically noisy environments.

MAIN FEATURES

- Simultaneous pH and temperature measurements on a large dual-line LCD display
- Automatic pH calibration at one or two points within two memorized buffer sets (standard or NIST)
- Selectable temperature unit (°C or °F)
- Electrode condition indicator
- mV of pH measurement for electrode check
- HI14143 dedicated pH with integrated temperature sensor
- Probe quick connect system
- Battery life indication and low battery detection
- · Keystroke confirmation tone
- Auto-off function
- Waterproof casing IP67




SPECIFICATIONS

Range*	-2.00 to 16.00 pH / -2.0 to 16.0 pH ±825 mV (pH-mV) -5.0 to 105.0 °C/23.0 to 221.0 °F
Resolution	0.01 pH / 0.1 pH 1 mV 0.1 °C/0.1 °F
Accuracy @ 25°C/77°F	$\begin{array}{l} \pm 0.02 \text{ pH} / \pm 0.1 \text{ pH} \\ \pm 1 \text{ mV (pH-mV)} \\ \pm 0.5 \text{ °C up to } 60 \text{ °C; } \pm 1.0 \text{ °C outside} \\ \pm 1.0 \text{ °F up to } 140 \text{ °F; } \pm 2.0 \text{ °F outside} \end{array}$
Temperature compensation	Automatic -5.0 to 105.0 °C/23.0 to 221.0 °F
pH calibration	Automatic, 1 or 2 point selectable buffer set Standard: 4.01; 7.01; 10.01 or NIST: 4.01; 6.86; 9.18
Probe (included)	HI14143 preamplified pH and temperature probe with flat tip, DIN connector and 1 m (3.3') cable
Battery type/life	1.5V AAA (3 pcs.) approx. 1400 hours of continuous use
Auto-off	user selectable: after 8 min, 60 min or disabled
Environment	0 to 50 °C (32 to 122 °F) RH max. 100%
Meter dimensions	154 x 63 x 30 mm (6.1 x 2.5 x 1.2")
Weight (with batteries)	196 g (6.91 oz.)
Case ingress protection rating	IP67

 $^{^{\}ast}$ the H114143 is limited to be used from 0 to 12 pH and from 0 to 50 °C temperature (32 to 122 °F).

DISPLAY DESCRIPTION

- 1 Automatic Temperature Compensation indicator
- 2 Stability indicator
- 3 Battery percentage
- 4 Electrode condition indicator
- 5 Low battery indicator
- 6 Measurement unit
- 7 Primary LCD
- 8 Temperature unit
- 9 Secondary LCD
- 10 Meter modes indicator
- 11 pH calibration buffer(s) used



OPERATIONAL GUIDE


Each meter is supplied with batteries. Before using the meter for the first time, open the battery compartment and insert batteries, observing the polarity (see "Battery Replacement").

CONNECTING THE ELECTRODE

With the meter turned off, connect the H114143 probe to the DIN socket on the bottom of the meter by aligning the pins and pushing in the plug firmly. Remove the protective cap from the probe before taking any measurements.

TURNING THE METER ON

To turn the meter ON, press the button on the front of the meter. If it does not turn on, make sure that the batteries are properly installed in their place. The meter is provided with an active acoustic signal when a key is pressed. At start-up the meter displays all LCD segments for a few seconds, followed by the percentage indication of the remaining battery life, displaying "WAIT" until electrode check is in process then the meter enters the normal measurement mode.



Note: The meter detects the presence and the type of the probe at its input.


- If the probe is not connected the message "NO" "PROBE" appears alternatively on the secondary LCD with "---" blinking on the first LCD line.
- If the probe is not compatible "WRONG" "PROBE" message appears alternatively on the secondary LCD with "---" blinking on the first LCD line.
- If the readings are out of range, the nearest range limits are displayed blinking (e.g. -2.00 pH -5.0 $^{\circ}$ C).

SFLECTING MEASUREMENT RANGE

While in measurement mode, press the **SET** button to select pH or pH-mV measurement on the first LCD line.

FREEZING MEASUREMENT VALUES

While in measurement mode, press and hold the **SET** button until "**HOLD**" appears on the secondary LCD. The "**HOLD**" remains for 1 second and reading of pH, mV and temperature will be frozen on the LCD with "H" blinking.



Press any button to resume active measurements.

ENTERING CALIBRATION MODE

Press and hold the button until "POWER" and si replaced by "STD" and sag. Release the button.

ENTERING SETUP MODE

Press and hold button until "STD" and CAL tag is replaced by "SETUP" and MODE tag.

Release the button.

TURNING THE METER OFF

While in measurement mode, press the **button**."**POWER**" and **DFF** tag will appear.

Release the button.

pH MEASUREMENT & CALIBRATION

Make sure the meter has been calibrated before use.

If the probe is dry, soak it in H170300 storage solution for 30 minutes to reactivate it. If soiled, clean the



electrode by soaking in cleaning solution for 20 minutes, then rinse the tip and soak in storage solution at least 30 minutes before use.

Rinse the electrode off well and shake off excess droplets. Recalibrate before using.

To prepare a solid sample, slice it very small and add a few drops of H170960.

Submerge the probe in the sample to be tested while stirring it gently. Wait until the \boxtimes tag on the LCD disappears.

The LCD displays the pH value (automatically compensated for temperature) on the primary LCD, while the secondary LCD displays the sample temperature. If measurements are taken in different samples successively, rinse the probe tip thoroughly in distilled or deionized water to eliminate crosscontamination.

For better accuracy, frequent calibration of the pH sensor with the meter is recommended. In addition, the meter must be recalibrated:

- a) whenever the pH electrode is replaced.
- b) after testing aggressive chemicals.
- c) when high accuracy is required.
- d) at least once a month.
- e) after cleaning the sensor.

pH calibration

Enter calibration mode while in pH measurement mode. Place the sensor into the first calibration buffer. If performing a two-point calibration, use pH 7.01 (pH 6.86 for NIST) buffer



first. The meter will enter the calibration mode, displaying "pH 7.01 USE" \bigcirc and \bigcirc tag blinking (or "pH 6.86 USE" for NIST).

Follow directions for single and two-point calibration below:

Single-point calibration

- 1. Place the probe in any buffer from the selected buffer set. The meter will automatically recognize the buffer value.
- 2. If the buffer is not recognized or the calibration offset is out of the accepted range "---- WRONG" is displayed.
- 3. If the buffer is recognized "REC" is displayed then "WAIT" until the calibration is accepted.

If using pH 7.01 (or pH 6.86 for NIST), after acceptance of the buffer press any key to exit. The "SAVE" message is displayed and the meter returns to pH measurement mode. If using pH 4.01 or 10.01 (or pH 9.18 for NIST) buffer the "SAVE" message is displayed and meter returns to pH measurement mode.

Two-point calibration

Proceed with steps 1 through 3 under single-point calibration using 7.01 (pH 6.86 for NIST) pH buffer first. Then follow steps below:

The "pH 4.01 USE" message is then displayed.

Place the probe in the second calibration buffer (pH 4.01 or 10.01, or, if using NIST, pH 4.01 or 9.18). When the second buffer is accepted, the LCD will display "SAVE" for 1 second and the meter will return to the normal measurement mode.

If the buffer is not recognized or the slope is out of accepted range "--- WRONG" is displayed. Change the buffer, clean the electrode or press any key to exit calibration.

For better accuracy it is always recommended to carry out a two-point calibration.

After the calibration procedure has been completed, the tag is turned on together with the calibrated points.

Exiting calibration and resetting default values

After entering the calibration mode and before the first point is accepted, it is possible to quit the procedure and return to the last calibration data by pressing the button. The LCD displays "ESC" for 1 second and the meter returns to normal mode.

To reset the default values and clear a previous calibration, press the **SET** button after entering the calibration mode and before the first point is accepted.

The LCD displays "CLEAR" for 1 second, the meter resets to the default calibration and the CAL tag with the calibrated points on the LCD disappears.

ELECTRODE CONDITION

The display is provided with a probe icon (unless the feature is disabled from setup) which indicates the electrode status after calibration. The "condition" remains active for 12 hours (unless the batteries are removed).

The electrode condition is evaluated only if the current calibration has two points.

5 bars: excellent condition 4 bars: very good condition 3 bars: good condition 2 bars: fair condition 1 bar: poor condition

1 bar blinking: very poor condition

With 1 bar it is recommended to clean the electrode and recalibrate. If there is still only 1 bar or 1 bar blinking replace the probe.

Sensor check

Setting the meter to pH-mV range the user can check the sensor status at any time. The offset value is the reading in pH 7.01 buffer (@ 25 °C/77 °F). If this reading is outside the range \pm 30 mV, the electrode is considered "very poor". The slope value of the sensor is the difference between readings in pH 7.01 and in pH 4.01 buffers. When the slope reaches the value of about 150 mV, the electrode is considered "very poor". When "poor" or "very poor", it is recommended to replace it with a new one.

Note: To ensure reliable readings, the electrode must be cleaned with cleaning solution and then hydrated in storage solution for a minimum of 30 minutes before calibrating the probe.

METER SETUP

Setup mode allows the selection of the Temperature unit, Auto-off, Beep confirmation tone, the type of pH buffer set, the Resolution and Information. To enter Setup mode press and hold button until "STD" and Lag is replaced by "SETUP" and Lag. Release the button.

 "TEMP" is displayed on the secondary LCD with the current temperature unit (e.g. "TEMP °C"), for °C/°F selection, use the SET



button. After the temperature unit has been selected, press to confirm and to enter the "A-OFF" selection.

 Use the SET button, to navigate through the auto-off choices: 8 minutes ("8", default value), 60 minutes ("60") or disabled ("---"). Press ("b) to confirm and to enter the "BEEP" selection.



 To switch the beep tone ON or OFF, press the SET button; press b to confirm and to enter the calibration buffer selection "pH 7.01 BUFF".



 To change the buffer set, the meter will show the current buffer set: "pH 7.01 BUFF" (for standard buffer set: 4.01/7.01/10.01) or "pH 6.86 BUFF" (for NIST buffer



set: 4.01/6.86/9.18). Change the set with the SET button. Press to confirm and to enter pH resolution selection "RESOL".

• To change the pH measurement resolution between "0.1" and "0.01" use the SET button; then press to confirm and to enter electrode calibration information "INFO" selection.



 To switch the electrode condition indicator on the LCD ON or OFF, press the SET button; press to exit setup options. Change the set with the SET button, then press to confirm and to return to normal mode.



BATTERY REPLACEMENT


When the remaining battery life is less than 10% the battery tag blinks on the display to warn the user.



Battery Error Prevention System (BEPS)

If the battery is too weak ("0%") the display shows "bAtt", "DEAD" for a few seconds then the meter powers off. Immediately replace the batteries with new ones.

The batteries are accessed by opening the battery cover on the back of the instrument. Remove protective boot if present.




Replace the three 1.5V AAA alkaline batteries located in the battery compartment, observing the indicated polarity.

Replace the battery cover making sure that the gasket is in place.



ACCESSORIES	S
HI14143	Combination preamplified pH/temperature probe with flat tip, DIN connector and 1 m (3.3') cable
HI7004L	pH 4.01 buffer solution, 500 mL
HI7006L	pH 6.86 buffer solution, 500 mL
HI7007L	pH 7.01 buffer solution, 500 mL
HI7009L	pH 9.18 buffer solution, 500 mL
HI7010L	pH 10.01 buffer solution, 500 mL
HI70300L	pH electrode storage solution, 500 mL
HI7061L	pH electrode cleaning solution, 500 mL
HI70680L	Cleaning solution for cellulose deposits, 500 mL
HI70960	Preparation solution for solid or semi- solid samples, 30 mL
HI710028	Orange silicon rubber boot
HI710142	Black carrying case for HI991XX portable instruments
HI76405	Electrode holder
HI77400P	Calibration kit (pH 4 and pH 7, 20 mL, 5 pcs. each)



ELECTRODE MAINTENANCE

PREPARATION

- Remove the protective cap. Do not be alarmed if any salt deposits are present. Rinse with water.
- Shake the electrode down as you would do with a clinical thermometer to eliminate any air bubbles inside the glass.
- If the glass and/or junction are dry, soak the electrode in H170300 Storage Solution for a minimum of 30 minutes.
- Rinse with water.
- Calibrate before using.

STORAGE

- To ensure a quick response, the glass and the junction should be kept moist and not allowed to dry.
- Replace protective cap with a few drops of HI70300 Storage Solution. Follow PREPARATION above before taking measurements.

Note: Never store the electrode in distilled water

PERIODIC MAINTENANCE

- Inspect the electrode for any scratches or cracks. If any present, replace the electrode.
- Rinse off any salt deposits with water.
- Follow the STORAGE procedure above.

CLEANING PROCEDURE

- Soak in Hanna HI7061 general cleaning solution or HI700680 electrode cleaning solution for cellulose deposits for 20 minutes. Rinse with water.
- Soak the electrode in H170300 Storage Solution for a minimum of 30 minutes. Rinse with water, Calibrate before using.

TROUBLESHOOTING

- pH Meter: Follow the meter's operating and calibration procedures.
- Electrode: Evaluate your electrode performance based on the *Sensor check* procedure on page 13.

CFRTIFICATION

All Hanna Instruments conform to the CE European Directives.



Disposal of Electrical & Electronic Equipment. The product should not be treated as household waste. Instead hand it over to the appropriate collection point for the recycling of electrical and electronic equipment which will conserve natural resources

Disposal of waste batteries. This product contains batteries, do not dispose of them with other household waste. Hand them over to the appropriate collection point for recycling.

Ensuring proper product and battery disposal prevents potential negative consequences for the environment and human health. For more information, contact your city, your local household waste disposal service, the place of purchase or go to www.hannainst.com.



Recommendations for users

Before using this product, make sure it is entirely suitable for your specific application and for the environment in which it is used. Any variation introduced by the user to the supplied equipment may degrade the meter's performance. For yours and the meter's safety do not use or store the meter in hazardous environments

Warranty

H199171 is warranted for two years against defects in workmanship and materials when used for its intended purpose and maintained according to instructions. Electrodes and probes are warranted for a period of six months. This warranty is limited to repair or replacement free of charge. Damage due to accidents, misuse, tampering or lack of prescribed maintenance is not covered.

If service is required, contact your local Hanna Instruments Office. If under warranty, report the model number, date of purchase, serial number (see engraved on the back of the meter) and the nature of the problem. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the meter is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization number from the Technical Service department and then send it with shipping costs prepaid. When shipping any meter, make sure it is properly packed for complete protection.

Hanna Instruments reserves the right to modify the design, construction or appearance of its products without advance notice.

World Headquarters Hanna Instruments Inc.

Hanna Instruments Inc. Highland Industrial Park 584 Park East Drive Woonsocket, RI 02895 USA www.hannainst.com

